
ACCURIZE



Warning !
Avoid direct eye exposure
Laser light . Keep away from
children.

USER MANUAL CAL .22LR LASER ACOUSTIC MODEL

1. **Never look directly at the laser. Never direct it to other people or animals. The laser can damage the eye.**
2. Align the laser at a wall, ceiling or floor.
3. Press in the black button for about 1 sec, one flash of light should appear on the wall, the ceiling or the floor. When light flashes are observed, the laser is turned on and ready for use.
4. Check that the weapon is not charged with ammunition.
5. The laser pin is inserted into the barrel from the mouth of the weapon until it is physically stopped. If it goes very tight, lubricate a little gun oil on the o-rings.
6. The laser is now ready to be used and will send laser shots to the target by pull-out, and at charge grips carried out after the time limit, **see NB! bottom.**
7. For calibration on the biathlon target, use the center target.
8. Press in black button 3- 5 sec and 5 quick flashes of light should be observed on the floor, ceiling or wall. **The laser is then turned off.**
9. The laser should ALWAYS be removed from the weapon after use. Do not forget it before using sharp ammunition.

Replacing the Battery

Battery can be purchased from your dealer and replaced by turning the laser top apart. Gently push the battery out by pressing a thin object on the back of the battery.

NB! The laser will send out laser shots also during charge grips, if the charging grips are not carried out within 1.2 seconds after extraction. This is built in to train increased speed on the shooting series, so you work into maximum speed of training.

